

Model DFM/DFM-BRK Fiber Optic Interface and Bracket for DNET

IMPORTANT!



Scan this QR code to access Installation Instructions for the Model DFM/DFM-BRK (A6V10239120) or go to: <https://www.siemens.com/download?A6V10239120>



CAUTION:

It is recommended that the printed circuit boards be removed for any procedure that may cause dust, metal shavings, grease or any such matter that may affect the circuit boards and/or parts. There may be several sources of power into the control unit. Each source must be disconnected prior to installing or connecting or disconnecting wiring.

Information in this publication is based on current specifications. The company reserves the right to make changes in specifications and models as design improvements are introduced. Products or company names mentioned herein may be the trademarks of their respective owners. © 2021 Siemens Industry, Inc.