








- de** Montageanleitung
- en** Mounting instructions
- fr** Instructions de montage
- sv** Monteringsinstruktion
- nl** Montage-handleiding
- it** Istruzioni di montaggio
- fi** Asennusohje
- es** Instrucciones de montaje
- da** Monteringsvejledning
- pl** Instrukcja montażu
- cz** Montážní návod
- hu** Szerelési útmutató
- el** Οδηγίες εγκατάστασης
- zh** 安裝指導

- Stellzeitmodul**
- Timer**
- Module additionnel**
- Ställtids-modul**
- Looptijd-moduul**
- Timer**
- Ajastin**
- Controlador de velocidad externo**
- Gangtids-modul**
- Moduł czasu przebiegu**
- Časový spínač**
- Időkapcsoló**
- Μονάδα χρόνου ανοίγματος**
- 計時器**



SEZ31.1



SEZ31.1	SQL36E65	SQL36E110
t_1	0.2 s	
$t_{2min} \dots t_{2max}$	0.8 ... 5.8 s	0.8 ... 5.8 s
\square (90° \rightarrow)	30x	60x
t (90° \rightarrow)	30 ... 180 s	60 ... 360 s

