

## Model PAD-4 Distributed Power Module NAC Expander

---

### IMPORTANT!



Scan this QR code to access the Installation Instructions and other important documentation for the Model PAD-4 Distributed Power Module NAC Expander (A6V10406110) or go to:  
<https://www.siemens.com/download?A6V10406110>



#### CAUTION:

It is recommended that the printed circuit boards be removed for any procedure that may cause dust, metal shavings, grease or any such matter that may affect the circuit boards and/or parts. There may be several sources of power into the control unit. Each source must be disconnected prior to installing or connecting or disconnecting wiring. Each output circuit is rated at 3 amps. **DO NOT OVERLOAD.** Overloading a circuit will cause it to shut down (power limit).

Information in this publication is based on current specifications. The company reserves the right to make changes in specifications and models as design improvements are introduced. Products or company names mentioned herein may be the trademarks of their respective owners. © 2021 Siemens Industry, Inc.

**Siemens Industry, Inc.**  
Smart Infrastructure  
8 Fernwood Road  
Florham Park, NJ 07932

Your feedback is important to us. If you have comments about this document, please send them to [SBT\\_technical.editor.us.sbt@siemens.com](mailto:SBT_technical.editor.us.sbt@siemens.com)

Printed in the USA  
**Page 1 of 1**

**Siemens Canada, Ltd.**  
1577 North Service Road East  
Oakville, Ontario L6H 0H6 Canada

Document ID A6V12344979\_en--\_a  
P/N A5W00161775